


JENSEN®
audio

JSR-1000

AM/FM STEREO POCKET RADIO

FUNCTIONS AND CONTROLS

1. Volume Control
2. Phones Socket
3. Power Switch
4. Super Bass Switch
5. Tuning Knob
6. Band Selector
7. Battery Door
8. Belt Clip



POWER SOURCE


This Pocket AM/FM Stereo Radio operates on 2 'AAA' size (UM-4) batteries(not included).

BATTERY INSTALLATION

1. Remove the Battery Door (#7).
2. Following the polarity diagram as shown in the battery compartment, insert 2 'AAA' Size (UM-4) batteries. Replace the battery Door.
IMPORTANT: Be sure that the batteries are installed correctly. Wrong polarity may damage the unit.
3. For better performance and longer operating time, we recommend the use of alkaline-type batteries.
4. Do not mix old and new batteries.
5. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
6. If the unit is not to be used for an extended period of time, remove the batteries. Old or leaking batteries can cause damage to the unit and may void the warranty.

USING THE BELT CLIP

Attach the supplied belt clip (# 8) to the unit and install it to your belt as illustrated in A-a. To detach the belt clip, follow the illustration shown in A-b.



A-a



A-b

RADIO RECEPTION

1. Connect the headphones to the Phones Socket (#2).
2. Slide the Power Switch (# 3) to the "ON" position.
3. Set the band Selector (# 6) to "AM", "FM" or "FM ST" for the desired radio band.
4. Turn the Tuning Control (# 5) to select the desired radio station.
5. Adjust the Volume Control (# 1) to obtain the desired sound level.

6. To emphasize the bass sound, slide the Super Bass Switch (# 4) to the right.
7. To turn the Radio off, slide the Power Switch (#3) to the "OFF" position.

TIPS FOR GOOD RADIO RECEPTION

1. The headphones cord functions as the FM antenna. Keep it extended.
2. When listening to a radio station in FM stereo, set the Band Selector(# 6) to "FM ST".
3. If the FM stereo signal is weak, set the Band Selector to "FM". The sound will be heard in monaural but the distortion will be reduced.
4. When tuning in AM reception, be sure to place the unit in a vertical position. To insure best AM sensitivity, try repositioning the unit until the best reception is obtained.

READ THIS IMPORTANT INFORMATION BEFORE USING YOUR HEADPHONES

1. Avoid extended play at very high volume as it may impair your hearing.
2. If you experience ringing in your ears, reduce the volume or shut off your unit.
3. Do not use while driving a motorized vehicle. This is dangerous and also illegal in some states.
4. Keep the volume at a reasonable level even if your headset is an open-air type designed to allow you to hear outside sounds. Please note excessive high volume may still block outside sounds.

CARE AND MAINTENANCE

1. Clean your unit with a damp (never wet) cloth. Solvent or detergent should never be used.
2. Avoid leaving your unit in direct sunlight or in hot, humid or dusty places.
3. Keep your unit away from heating appliances and sources of electrical noise such as fluorescent lamp or motors.

COMPLIANCE WITH FCC REGULATIONS

This equipment has been tested and found to comply with the limits for a Radio Receiver, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio technician for help.

WARNING

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SERVICE

Please refer to the instructions on the enclosed warranty card for returning your unit for service. When returning the unit, Please remove batteries to prevent damage to the unit in transit and/ or from possible battery leakage. We are not responsible for batteries returned with the product or for the cost of replacement.

Distributed by:
Spectra Merchandising International, Inc.
Chicago Industry Tech Park
4230 North Normandy Avenue
Chicago, Illinois 60634, U.S.A.

Printed in China